

# Golden Public Works Department Standard Operating Procedure

**NUMBER:** 26.9

**TITLE:** Loading Procedures for Snow and Ice Control Materials

## GENERAL PROCEDURE:

1. Street Division staff will use front end loaders to load the spreaders.
2. A maximum of 2.5 bucket loads per single axle spreader will be loaded.
3. A maximum of 4 bucket loads per tandem axel spreader will be loaded.
4. Front end loader operators will center the loads and not overload the spreaders.
5. All front-end loader operators will be trained in the operation of the loaders prior to loading any snow and ice control materials into the spreaders. Training can be provided by other Streets Division staff who have been trained in loader operations, or by organized training classes such as those provided by the Heavy Equipment Institute, CIRSA, or others.

## MISCELLANEOUS NOTES and COMMENTS:

None.

**S.O.P prepared by:** Stephen M. Kurtz

**Date:** July 9, 2022  
**Revised:** Nov. 1, 2007  
**Reviewed:** Dec. 20, 2011  
Jan. 15, 2016  
April 29, 2020  
Oct. 17, 2023

**Approved by:**   
Anne Beierle  
Public Works Director

**Date:** Oct. 17, 2023